

				FRONT BUMPER		
1	16	12.168	213512	Bar-impact	1	1948,1949
1	16	12.168	220310	Bar-impact	1	1950
1	16	12.168	225287	Bar-impact	1	1951,1952,4C,5C,7C
1	16	12.168	240239	Bar-impact	1	4D,5D,6D,7D
1	16	12.168	235900	Bar-impact	1	1C,2C,1D,2D,3D
2	16	12.168	235140	Screw-impact bar	2-6	1948-1954
3	16	12.170	213519	Spacer-impact bar to frame bar	2-6	1948-1954
		12.168	215555	Washer-impact bar screw	2	1948-1950,4A,5A,6A,8A, 4B,5B,6B,8B,4C,5C
4	16	17.126	GM120383	L/washer-impact bar screw	2-6	1948-1954
5	16	17.032	GM124573	Nut-impact bar screw	2-6	1948-1954
6	16	12.175	225286	Bar-impact to frame	2	1948-1952,4C,5C,7C
6	16	12.175	240820	Bar-impact to frame-RH	1	4D,5D,6D,7D
6	16	12.175	240821	Bar-impact to frame-LH	1	4D,5D,6D,7D
		12.175	235908	Bar-impact to frame-RH	1	1C,2C,1D,2D,3D
		12.175	235909	Bar-impact to frame-LH	1	1C,2C,1D,2D,3D
7	16	17.076	GM181670	Screw-frame bar to frame	4	1948-1954
8	16	17.136	71356	P/washer-frame bar to screw	4	1948-1954
9	16	17.126	GM120383	L/washer-frame bar to screw	4	1948-1954
10	16	17.032	GM115730	Nut-frame bar to screw	4	1948-1954
		12.184	213532	Guard-inner-RH	1	481,483,491,493
		12.184	213533	Guard-inner-LH	1	481,483,491,493
		12.184	213530	Guard-inner-RH	1	482,484,492,494
		12.184	213531	Guard-inner-LH	1	482,484,492,494
		12.184	226874	Guard-inner-RH	1	500,50A,4A,4B,5B,4C,5C, 4D,5D,6D
		12.184	226875	Guard-inner-LH	1	500,50A,4A,4B,5B,4C,5C, 4D,5D,6D
		12.184	225270	Guard-inner	1	5A,6A,7A,8A,6B,7B,8B,7C
		12.184	240878	Guard-inner-RH	1	7D
G11-				FRONT BUMPER (Cont'd.)		
		12.184	240879	Guard-inner-LH	1	7D
		12.184	235904	Guard-inner	2	1C,2C,1D,2D,3D
12	16	12.184	220330	Guard-outer-RH	1	502,504
12	16	12.184	220331	Guard-outer-LH	1	502,504
12	16	12.184	225274	Guard-outer-RH	1	482,484,492,494,501,502, 503,504,6A,7A,8A
12	16	12.184	225275	Guard-outer-LH	1	482,484,492,494,501,,502, 503,504,6A,7A,8A
		12.184	225094	Guard-outer-RH	1	6B
		12.184	225095	Guard-outer-LH	1	6B
		12.184	230814	Guard-outer-RH	1	7B,8B,7C
				Guard-outer-RH	1	7B,8B,7C